Welcome to RISC OS 4

Read This First

Box contents

Inside this box you should have:

2 x RISC OS 4 OTP ROMs (ROM 1 & 2)
1 x RISC OS 4 Installation CD
1 x RISC OS 4 Fitting manual and notes
1 x RISC OS 4 Registration card
1 x Writer Registration card
1 x Writer upgrade form
1 x ROM personalisation request form
This sheet

Overview of installation

Since many people will not want to wade through the fitting instructions, there follows a summary of the installation steps:

1) If you have never upgraded your RISC OS computer's operating system before ***read and follow the manual***
2) If you want to be safe ***read the manual***
3) Uninstall any protected software applications
4) Use *Checkmap to check your hard disc for errors
5) Install the software from the CD using current RISCOS
6) Check your machine is working
7) Install the RISC OS 4 ROMs
8) Make sure everything is working correctly
9) Backup all your data
10) (Optionally) Reformat hard disc to new format
11) Restore data and reboot